

Installation instructions

Mini-Speedy 1050 for Atari 1050 drive

Hi Atari fan!

thanks for your purchase of this item. The box contains the prebuilt and ready-to-use PCB "Mini-Speedy 1050" and this installation instructions.

Attention:

The following instructions don't require professional skills in soldering or tinkering with electronic components, but if you've never open an Atari 1050 drive before, it's a good idea to ask a experienced friend for assistance.

These instructions doesn't contain any solder guide or "how to" – you have to have the knowledge ☺

Please follow these steps:

1. Open your Atari 1050 drive case and remove the drive mechanic.

Hint: Make a photo of the cables coming from the drive mechanic and connected on the 1050's PCB. Mark every single plug with a permanent marker to remember it's position and direction. Without this remedy it's very difficult to reassemble the mechanic again.

2. Remove the CPU (6507, socket U9) and ROM or EPROM at socket U10. Take a look at **figure 1**. Keep both parts for the possibility to make your 1050 original again, if ever wanted.
3. Insert the Mini-Speedy PCB into the CPU's Socket (U9) as shown in **figure 2**. The EPROM with white label must be placed on the left side. A small part of the PCB will rest on the upper side of the blue trim pot – this is intended and used for better fitting of the whole Mini-Speedy PCB.
4. Remove four capacitors (C56, C57, C58 and C61) as shown in **figure 3**. The removal of these caps is needed to make the highspeed-mode of your Speedy work fine. These caps must never be installed again, even if your want to use the drive without Speedy or with any other enhancement.
5. Connect the mechanic again using your photos. Only connect the power cord to your drive. Switch the drive on and observe the mechanic. The motor starts spinning for a short time and the read-write-head's carriage will move for- and backward. The time after the motor stops is much less comparing to an original 1050 without Speedy.
6. Switch the drive off, plug SIO-cable and computer to the drive, power on all devices and test the drive the usual way. All operations should work normally.
7. Reassemble the case of your 1050. The work is done!

(please turn page)

(Continued from other side)

When you start using your Speedy equipped 1050 drive, you should notice that reading from disk is some times faster than normal. This is the result of having a trackbuffer on the Speedy PCB. The Speedy always reads the whole track into this RAM and sectors-to-read could be accessed much faster.

You will get the real highspeed experience using DOS versions or GameDOS loaders with integrated highspeed-SIO routines. Or install a modified operating system into your computer with highspeed-SIO routines and nearly everything will be loading with maximum speed.

Some DOS and GameDOS loaders with highspeed support:

- SpartaDOS X (SDX) V4.xx
- Happy DOS 1050 (Single/Medium/Double Density enabled DOS 2.x clone from HCI)
- TOP DOS (some variants)
- XDOS 2.xx from Stefan Dorndorf (two versions; one with, one w/o Highspeed-SIO)
- PicoDOS from HiasSoft (GameDOS-Loader)
- BiboDOS 6.xx (from the developer of the Speedy, Compy-Shop)
- ... and more

Most of the listed DOS versions (and more) you can get at the download pages on the ABBUC website (www.abbuc.de) and other Atari-related websites. For the Speedy series there are two system-discs available, one tooldisc and one BiboDOS disc. The tooldisc contains diagnostic and test utilities, copy programs and more.

After closing the business at Compy Shop, the developer of the Speedy series, the rights about Speedy and Speedy-related material was transferred to the ABBUC e.V. – so the Speedy systemdiscs are only downloadable at the member area of the ABBUC website. You must be registered to get these files.

You will find the Speedy systemdiscs in the member download area of www.abbuc.de and a lot of different sources on the Internet, just use Google. At ABBUC.DE, search for the download number **0649 - Speedy System Disk SD/1S**. BiboDOS 6.xx you will find at download **0764 - Bibo-DOS System Diskette 1988 SD/1S**

Please keep in mind that “Compy Shop” was a german company and most of the stuff programmed by them is only available in german language. But in most cases you can use it anyway, if some words or sentences aren’t clear, use the Google translator for help - it’s translation quality is good enough to understand what’s going on.

With exclusion of the four capacitor’s removal there’s no changing on the drive’s hardware, so that any fine working drive should be also work fine after installing the Mini-Speedy PCB.

Earch „Mini-Speedy 1050“ PCB was built into a 1050 drive for test. Formatting, Writing and Reading back of a disc were performed. Readout disc compared with the source. You get a fully tested and working PCB. Any technical issue with the Mini-Speedy 1050 PCB is very implausible.

In case of any trouble with your Mini-Speedy 1050 equipped 1050 drive please contact an experienced friend for assistance.

Installationsanleitung

Mini-Speedy 1050 für Atari 1050 Laufwerk

Hallo Atari-Fan!

Vielen Dank für den Erwerb dieser Hardware. Im Karton findest Du die fertig aufgebaute Platine „Mini-Speedy 1050“ und diese Installationsanleitung.

Hinweis:

Die folgenden Arbeiten sind eigentlich sehr leicht und einfach durchzuführen. Wenn Du bisher keine Erfahrungen damit gemacht hast und unsicher bist, empfehle ich Dir jedoch, einen Freund mit entsprechenden Kenntnissen um Hilfe zu bitten.

Diese Anleitung beinhaltet absichtlich keine Lötanleitungen und/oder Hinweise, welches Werkzeug benötigt wird. Es wird davon ausgegangen, daß diese Dinge bekannt sind ☺

Folgende Schritte sind durchzuführen:

1. Öffnen des Atari 1050 Diskettenlaufwerkes und Demontage der Mechanik.

Tipp: Ein Foto von den Kabeln machen, BEVOR diese abgezogen werden. Oder jeden Stecker einzeln ziehen und für Dich sinnvoll beschriften (Edding, Folienschreiber etc.). Markiere dabei auch die Steckrichtung!

2. Entfernung der CPU (6507, Steckplatz U9) und des ROM bzw. EPROM aus Steckplatz U10 – siehe dazu **Abbildung 1**. Bewahre beide Bauteile auf, falls Du den Urzustand wieder herstellen möchtest.
3. Stecke die Mini-Speedy Platine so in den Sockel der CPU (U9) wie in **Abbildung 2** ersichtlich. Das auf der Mini-Speedy befindliche EPROM mit dem weißen Aufkleber muß sich auf der linken Seite befinden. Ein kleiner Teil der Mini-Speedy Platine liegt auf dem Trimm-Potentiometer (blau) auf – das ist in Ordnung und gewollt, um der Platine zusätzlichen Halt zu geben.
4. Entferne die vier Kondensatoren C56, C57, C58 und C61 wie in **Abbildung 3** zu sehen. Dieses ist notwendig, damit der Highspeed-Modus der Speedy einwandfrei funktioniert. Diese Kondensatoren müssen nicht zurückgebaut werden, wenn die Speedy wieder ausgebaut werden sollte.
5. Schließe die Mechanik wieder korrekt an und versorge das Laufwerk erstmal nur mit Strom. Beim Einschalten läuft der Motor kurz an und der Kopfschlitten bewegt sich kurz. Der Motor geht viel schneller wieder aus als bei einer Original 1050 ohne Speedy, dies ist normal ☺
6. Schalte das Laufwerk aus, schließe ein SIO-Kabel und einen Rechner an und teste das Laufwerk im “normalem Betrieb”. Es sollte einwandfrei funktionieren.
7. Baue die 1050 wieder zusammen. Der Einbau ist damit beendet.

(Bitte umblättern)

(Fortsetzung von anderer Seite)

Bei deinem Test wird Dir aufgefallen sein, daß das Laden von Diskette schon deutlich schneller vonstatten geht. Dies liegt am Trackbuffer der Speedy, diese liest nach dem Spurwechsel den gesamten Track in das auf der Speedy befindliche RAM ein und damit muß ein Sektor nicht erst gesucht werden bzw. abgewartet werden, bis der gewünschte Sektor unter dem Schreib-/Lesekopf vorbeirauscht.

So richtig Dampf entwickelt Deine Speedy aber erst, wenn Du ein DOS, ein GameDOS-Loader oder ein modifiziertes Betriebssystem mit sogenannten Highspeed-SIO Routinen verwendest. Alle aktuellen, in den letzten 10-15 Jahren entwickelten oder modernisierten DOS Versionen haben (ggf. optional) Highspeed-SIO-Routinen "ab Werk". Hier ein paar Beispiele (ohne Gewähr und Wertung):

- SpartaDOS X (SDX) V4.xx
- Happy DOS 1050 (Single/Medium/Double Density DOS Derivat von HCI)
- TOP DOS (und unzählige Derivate davon)
- XDOS 2.xx von Stefan Dorndorf (zwei Versionen, 1x mit, 1x ohne Highspeed-SIO)
- PicoDOS von HiasSoft (GameDOS-Loader)
- BiboDOS 6.xx (von den Entwicklern der ursprünglichen Speedy, Compy-Shop)
- uvm.

Die meisten dieser DOS-Versionen findest Du in den Download-Seiten von www.abbuc.de und vielen anderen Atari-Webseiten. Für alle Speedy-Versionen gibt es ehemals vom Compy-Shop entwickelte Systemdisketten zur Speedy. Auf diesen befindet sich eine Vollversion des BiboDOS als auch Test- und Diagnose-Software für die Speedy, Highspeed-Kopierprogramme uvm.

Die Rechte für die Speedy liegen beim ABBUC, demzufolge findest Du auch dort die Speedy Systemsoftware zum Download. Es ist eine Registrierung auf www.abbuc.de für den Download erforderlich.

Die Speedy-Systemsoftware findest Du im Mitglieder-Bereich unter Download-Nr. **0649 - Speedy System Disk SD/1S**. Das BiboDOS 6.xx findest Du unter dem Download **0764 - Bibo-DOS System Diskette 1988 SD/1S**

Da außer dem Entfernen der Kondensatoren kein wirklicher Eingriff an der 1050 vorgenommen wird, sind – sofern das Laufwerk vor dem Umbau einwandfrei funktionierte – keine Probleme zu erwarten.

Jede Platine „Mini-Speedy 1050“ wurde vor dem Einpacken einzeln in ein Atari 1050 Diskettenlaufwerk eingebaut, eine Diskette formatiert, beschrieben und anschließend eingelesen und mit der Quelle verglichen – im Highspeed-Modus. Ein Fehler an der Platine ist demzufolge eigentlich auszuschließen.

Wende Dich bitte an einen erfahrenen Freund, wenn der Einbau der Speedy bei Dir zu Problemen führen sollte.




Abbildung / Figure 1




Abbildung / Figure 2




Abbildung / Figure 3



MDC '82 MD2793A-PL
02-04 2445 4866X0X
BC2193PL-1070
PHILIPPINES

AM1 8H486MM
.S6810P
PHILIPPINES

RG532P
RG532-11
KOREA J4
5448
8443

188057-1

74221M K8336
5A

74LS 86
74LS 86

74LS 74A
74LS 74A

P8416
DM7406N

4M28
HD74LS04P

74LS 123
74LS 123

74LS 74A
74LS 74A

TBA331
SSS 98427